

# T2-841-22-CC1

Action: Designed to turn/roll...by default is always LOCKED

Benefits: The CADDIE enables a caregiver to move a seated

person up-to and away-from the table without the

need to push / pull / shove / twist.

Features: DIY...A metal platform complete with 2 inline and

2 rotating casters which attaches to the base of an existing chair. One of the casters includes a foot /

toe activated locking lever.



Shown in Stratford Pomegranate & Matrix Teak

## **-**2-841-2

### **T2-841-22"-CC** (Caddie)

- Steel Frame
- 3" Cold Cured Foam Seat
- Waterfall Seat Cushion
- 1.5" Foam Cushioning Back
- Lumbar Support
- Heavy Duty Poly Arm Caps
- Antimicrobial / Crypton Fabrics & Vinyls
- Hand Activated Release
- Caddie Undercarriage: Fits Inside the Frame of the Chair to Eliminate Tripping Hazzards
- Casters: Front Legs 4" Dia. Rear Legs - 3" Dia. Swivel
- 25 Year Warranty on Frame
- 15 Year Warranty on Cold Cured Foam
- 10 Year Warranty on Components
- 5 Year Warranty on Fabric

### FRONT WHEELS ARE ALWAYS LOCKED FOR SAFETY



LOCKED
Front wheels are always locked to ensure the

safety of the resident.



TO UNLOCK
The caregiver lifts the handle positioned at the top of the back.

#### **SPECIFICATIONS**

CAL 117E Approved ANSI / BIFMA Approved

**Dimensions:** 22"W x 24"D x 341/2"H

Cushion: 20"W x 17"D Seat Height: 18" Arm Height: 25½" Weight: 40 Lbs.

Weight Capacity: 400 Lbs.

C.O.M.: 1.3\* Yards

\* No Repeats on C.O.M.





T2-Caddie-11/18



www.comfortek.com/titan 1.888.678.2060

